Hoses and Clamps - Inspect/Replace 72 i01962655 Radiator - Clean 73 **Maintenance Interval Schedule Every 1000 Service Hours** Engine Valve Lash - Inspect/Adjust 67 Ensure that the Safety Information, Warnings, and Instructions are read and understood before operation or maintenance procedures are **Every 2000 Service Hours** performed. Aftercooler Core - Inspect 53 Alternator - Inspect 54 Before each consecutive interval is performed, all Crankshaft Vibration Damper - Inspect 58 of the maintenance requirements from the previous interval must also be performed. Note: For engine cooling systems that contain Perkins antifreeze, replace the coolant in the engine Water Pump - Inspect 77 cooling system at 2 yearly intervals. For engine cooling systems that contain an inhibitor, replace the **Every 2 Years** coolant in the engine cooling system at 6 monthly Cooling System Coolant - Change 56 intervals. **Every 4000 Service Hours** When Required Aftercooler Core - Clean/Test 53 Battery - Replace 55 Battery or Battery Cable - Disconnect 56 **Every 8000 Service Hours** Engine - Clean 59 Engine Air Cleaner Element (Dual Element) -Engine Crankcase Breather - Replace 62 Clean/Replace 59 Engine Oil Sample - Obtain64 Fuel Injection Nozzles - Test/Exchange 67 Fuel System - Prime 68 Severe Service Application - Check 74 Daily Cooling System Coolant Level - Check 57 Driven Equipment - Check 59 Engine Air Cleaner Service Indicator - Inspect 61 Engine Oil Level - Check 64 Fuel System Primary Filter/Water Separator -Walk-Around Inspection 76 **Every 500 Service Hours or 1 Year** Air Compressor Filter - Clean/Replace 54 Alternator and Fan Belts - Inspect/Adjust/ Replace 54 Battery Electrolyte Level - Check 55 Cooling System Coolant - Test/Add 57 Cylinder Head Grounding Stud - Inspect/Clean/ Tighten 58 Engine Air Cleaner Element (Dual Element) -Clean/Replace 59 Engine Crankcase Breather Element - Replace ... 63 Engine Oil and Filter - Change 65 Fuel System Primary Filter/Water Separator Element - Replace 70 Fuel System Secondary Filter - Replace 71 Fuel Transfer Pump Strainer - Clean 71

This document has been printed from SPI². Not for Resale